Change the Linetype of an Object

An object's [LINETYPE](#) can be changed in three different ways:

- If an object's linetype is set to BYLAYER, move it to another layer with a different linetype, the object will acquire the linetype of new layer.
- Choose another linetype for layer, all objects with a BYLAYER linetype on this layer will be automatically updated.
- Choose a specific linetype for the single object overriding the layer's linetype. You can do that for each single object on the layer.

Online URL: https://www.kb2.gstarcad.com.my/article.php?id=2483