

What is OFFSETGAPTYPE variable?

1128 kbadmin April 3, 2016 [System Variables](#) 0 4144

This system variable can have a drastic effect on the appearance of offsets. It's stored in the registry so it affects all drawings. The initial value is 0.

- 1 Fills the gaps with a filleted arc segment (the radius of the arc segment is equal to the offset distance)
- 2 Fills the gaps with a chamfered line segment

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1128>