

How do I change Mtext to lower or upper case?

1231 kbadmin June 30, 2021 [Annotation](#) 0 3525

You might make a mistake and want to change the text case... either to lower or upper case. Do you need to re-type it?

No way! It is easy to do. Select the word you want to change for. Right click in the word, select the CHANGE CASE option> Lower case or Upper case from the context menu.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1231>