

## CMLSTYLE system variable

1385 GstarCAD MY /KW July 9, 2021 [System Variables](#) 0 2622

### Function Description:

The **CMLSTYLE** system variable is used to set the multiple styles for multiple line appearance.

**Type** : Strings

**Saved in** : Drawing

**Initial value** : Standard

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1385>