

## CPLOTSTYLE system variable

1389 GstarCAD MY /KW July 9, 2021 [System Variables](#) 0 2294

### Function Description:

The **CPLOTSTYLE** system variable is used to control current plot styles for new objects.

**Type** : Strings

**Saved in** : Drawing

**Initial value** : ByColor

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1389>