

FILLETRAD system variable

1567 GstarCAD MY /KW July 15, 2021 [System Variables](#) 0 1275

Function Description:

The **FILLETRAD** system variable is used to store the current fillet radius for 2D objects.

Type : Real

Saved in : Drawing

Initial value : 0.0000

If modified **2D** fillet radius by **FILLET** command, the value of **FILLETRAD** system variable will change to match its radius value.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1567>