

GRIPHOVER system variable

1595 GstarCAD MY /KW July 16, 2021 [System Variables](#) 0 1172

Function Description:

The **GRIPHOVER** system variable is used to control the hatch color of grips when the cursor temporarily hover on it without selection.

Type : Integer

Saved in : Registry

Initial value : 11

Range : 1 ~ 255

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1595>