

MATERIALSPATH system variable

1695 GstarCAD MY /KW July 21, 2021 [System Variables](#) 0 997

Function Description:

The **MATERIALSPATH** system variable is used to specify the path for materials library.
(Read-Only)

Type : Strings

Saved in : Users-settings

Initial value : Unknown

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1695>