

PREVIEWEFFECT system variable

1763 GstarCAD MY /KW July 23, 2021 [System Variables](#) 0 1338

Function Description:

The **PREVIEWEFFECT** system variable is used to specify the preview visual effect when selecting objects.

Type : Integer

Saved in : Not saved

Initial value : 2

Range : 0,1,2

System Variable Value:

0 : dashed(default display style for selected objects)

1 : bold line

2 : dashed and bold line

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1763>