

REFEDITNAME system variable

1790 GstarCAD MY /KW July 26, 2021 [System Variables](#) 0 1156

Function Description:

The **REFEDITNAME** system variable is used to display the name of the reference being editing.
(Read-Only)

Type : Strings

Saved in : Not saved

Initial value : ""

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1790>