

SAVEFILEPATH system variable

1799 GstarCAD MY /KW July 26, 2021 [System Variables](#) 0 1136

Function Description:

The **SAVEFILEPATH** system variable is used to specify the path for automatically saved file directory in current task.

Type : Strings

Saved in : Registry

Initial value : Unknown

Users could also change it in Option dialog box.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1799>