

# SELECTIONPREVIEW system variable

1807 GstarCAD MY /KW July 26, 2021 [System Variables](#) 0 1247

## Function Description:

The **SELECTIONPREVIEW** system variable is used to control the display of selection preview.

**Type** : Bitcode

**Saved in** : Registry

**Initial value** : 3

**Range** : 0,1,2

The object will be highlighted when pickbox cursor rolling over objects. It means this object could be selected by clicking.

## System Variable Value:

**0** : turn off

**1** : turn on when there is no active command

**2** : turn on when prompts to select objects

Note: when the **COMMANDPREVIEW** is on, it ignores the **SELECTIONPREVIEW** system variable.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1807>