

SORTENTS system variable

1833 GstarCAD MY /KW July 27, 2021 [System Variables](#) 0 1237

Function Description:

The **SORTENTS** system variable is used to control object sorting to support drawing order for several operations.

Type : Integer

Saved in : Drawing

Initial value : 127

Range : 0,1,2,4,8,16,32,64

The setting is stored as a bitcode using the sum of listed system variable values.

System Variable Value:

0 : close all object sorting

1 : sort for selected objects

2 : sort for object snaps

4 :disabled

8 :disabled

16 : sort by REGEN command

32 :sort for plotting

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1833>