

ZOOMFACTOR system variable

1881 GstarCAD MY /KW July 27, 2021 [System Variables](#) 0 1060

Function Description:

The **ZOOMFACTOR** system variable is used to control how much the magnification changes when the mouse wheel moves forward or backward.

Type : Integer

Saved in : Registry

Initial value : 60

Range : 3 ~ 100

The larger of the value, the greater of the change.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1881>