

DRAGMODE command

2098 GstarCAD MY /KW August 12, 2021 [CAD Commands](#) 0 1670

The **DRAGMODE** command is used to control the way of display when dragging object.

Command Access:

Command : DRAGMODE

Command Prompts:

Enter new value [ON/OFF/Auto] <Auto>:

Relative Glossary:

On : Allow dragging objects, but users need to input "drag" in proper position when drawing or editing command.

Off : Forbid to drag objects, even drag requirement embedded in menu.

Auto : Users could drag objects if possible. It is no need to input "drag" every time.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=2098>