

FIELD command

2125 GstarCAD MY /KW August 13, 2021 [CAD Commands](#) 0 1235

The **FIELD** command is used to create multiple texts with field. The text could automatically update as the field changing.

Command Access:

Ribbon : Insert > Data > Field


Menu : Insert > Field

Command : FIELD

Shortcut : right-click when editing text by In-place text editor and click "Insert Field"

Function Description:

The FIELD command could insert all kinds of formats to text except tolerance. The FIELDEVAL system variable and the UPDATEFIELD command could determine the field updating modes.



Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=2125>