

PAN command

2269 GstarCAD MY /KW August 19, 2021 [CAD Commands](#) 0 1638

The **PAN** command is used to move view planar to the screen.

Command Access:

Ribbon : View > Navigate 2D > Pan

Menu : View > Pan > Realtime

Command : PAN

Command Prompts:

Press Esc or the Enter keys to exit, or right click to display the shortcut menu.

Function Description:

Users could specify the moving displacement by inputting "-pan" in the command prompt line. Place the cross cursor to the start position and press the mouse button, and then move the cross cursor to the new position, the view plane is moved along the mouse. Users could also press the mouse wheel or middle mouse button to move.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=2269>