## **REGENAUTO** command

2324 GstarCAD MY /KW August 20, 2021 CAD Commands 0 1362

The **REGENAUTO** command is used to control regeneration of drawings automatically.

**Command Access:** 

**Command** : REGENAUTO

Command Prompts:

Import mode [ON/OFF] :

Function Description:

ON:

If there are forbidden operations of regeneration in queue, it will regenerate drawing immediately. The REGENAUTO command could regenerate drawings at any time.

## **OFF:**

It is forbidden to regenerate drawings except using the REGEN or REGENALL command or turning on the REGENAUTO system variable.

Online URL: https://www.kb2.gstarcad.com.my/article.php?id=2324