

## VPMIN command

2431 GstarCAD MY /KW August 25, 2021 [CAD Commands](#) 0 1128

The **VPMIN** command is used to restore the current viewport.

### **Command Access:**

**Command :** VPMIN

### **Function Description:**

The settings of circle center and scale factor will be restored as maximized before.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=2431>