Unmask Text

2633 GstarCAD MY /KW November 11, 2021 Workflow 0 1098

Removes mask from text that has been masked with the TEXTMASK command

Menu: Express>Text>Unmask Text

Command Entry: TEXTUNMASK

Command line prompts as follow:

Select text or MText object from which mask is to be removed.

Select object: Use an object selection method.



Online URL: <u>https://www.kb2.gstarcad.com.my/article.php?id=2633</u>